



BITSTREAM™

power • data • fire over ethernet

BTS500-8R



LifeSafety Power, Inc. | PH 888.577.2898 | TechSupport@LifeSafetyPower.com

Table of Contents



Notes and Warnings	iii
Symbol Definitions	iii
Warnings	iii
Regulatory Information	iii
Conventions Used Within this Manual	iii
Introduction	iv
Product Description	iv
The BTS500 Series	iv
Section 1 – Installation	1
1.1 Mounting the BTS500 Rack Mount Supply into a Standard 19" Rack	1
1.2 BTS500 Rackmount Power Supply Overview	2
1.3 Using the Fire Alarm Input for SFI Mode	4
Section 2 – Initial Configuration	5
2.1 Preparing to configure the BTS500	5
2.2 Logging into PowerComPoE for the first time	5
2.3 Configuring the TCP/IP Settings	7
2.4 Configuring the Time Settings	7
2.5 MSM Settings	7
2.6 Configuring the SNMP Settings	7
2.7 Configuring the Email Settings	9
2.8 VPN Settings	9
2.9 General Settings	11
2.10 User Settings	11
2.11 Certificate Settings	11
2.12 SSL and CipherSuite Settings	11
2.13 Certificate Log	11
2.14 Import & Export Configuration File	11
2.15 IEEE802.1x Settings and Log	11
2.16 User Login Record	11
2.17 The Programming Page	13
Section 3 – Using the BTS500	14
3.1 Viewing System Parameters on the BTS500 Home Page	14
3.2 The Tools page	16
Appendix 1 – Software Agreement	18










Notes and Warnings

Symbol Definitions

The following symbols are used throughout this manual

-  This symbol is intended to alert the installer of shock hazards within the enclosure. Service should only be performed by qualified service personnel
-  This symbol is intended to alert the installer of important information intended to help the installer avoid personal injury or property damage

Warnings

-  Installation and service should be performed only by qualified service personnel and should conform to all local codes
-  To reduce the risk of electric shock or fire, do not expose this equipment to rain or moisture
-  This equipment shall be installed in a manner which prevents unintentional operation by employees, cleaning personnel, or others working in the premises, by falling objects, customers, building vibration, or similar causes
-  This equipment is not intended for use within the patient care areas of a Health Care Facility
-  Replace fuses only with the same type and rating as indicated in the specifications section of this manual.
-  To prevent impaired operation, ensure that all wiring is routed and secured to prevent accidental open or short circuit conditions
-  The system and any batteries (if used) should be tested at least once per year to ensure proper operation

Regulatory Information

The equipment discussed within this manual has been tested to the following standards:

- UL294
- EN60950 EN55022 CLASS A EN55024
- CE



FCC Information

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Conventions Used Within this Manual

Positional information (e.g. top, bottom, up, down, left, right, etc.) is referenced with the board or enclosure in the orientation shown in the illustrations in this manual

Introduction

Product Description

The BitStream BTS500 series of multi-port PoE switches are designed to provide PoE power with battery backup to 802.3bt compatible IP devices such as access control panels, IP surveillance cameras, IP phones, locks, IR illuminators and other PoE compatible access control edge devices. The BTS500 series products provide up to 90W of power per port and are compliant with the IEEE 802.3bt standard.

The chart below shows the models in the BTS500 product family.

BTS500 Midpsan Injectors

Model No.	Description	Notes
BTS500-8R	8 port / 90W per port 500 Watts Unmanaged Switch	Battery backup, SFI Mode, 802.3bt compatible

The BTS500 series is compatible with the BX50 PoE splitter with Single-point Fire Interface (SFI) and the BX75 with local fire alarm disconnect. Single-point Fire Interface (SFI) mode is a proprietary mode compatible with the BX50 PoE splitter. SFI mode allows a single FACP connection at the BTS500 switch to drop lock power on all connected BX50 splitters, eliminating the need for an FACP connection at each door.

All models are fully network managed and are capable of charging battery sets from 4 to 18 amhours utilizing an internal float charger for central battery backup without excessive loading of the rack UPS.

Specifications

Input voltage range	90 – 265 VAC
Input frequency	47 – 63 Hz
Power Factor / Current THD	> 0.9 / <10%
Total Output Power	500W
Max Power per Port	90W
Network Speed	10/100/1000
Battery Voltage	48V

Section 1 – Installation

The following pages cover the installation of the BTS500 Series rack-mountable PoE switches.

1.1 Mounting the BTS500 into a Standard 19" Rack

Use the following procedure when mounting a BTS500 series switch into a standard EIA 19" equipment rack.

1. If not already, securely mount the included ears to the front of the enclosure sides using the eight included countersunk screws (four per ear).
2. Locate the rack-mounting holes in the ears of the enclosure. (Figure 1)
3. Slide the enclosure into an open 1U location in the rack
4. Center the enclosure in the rack and secure with the four 10-32 x 3/4" screws provided.

NOTE: Use rails or other appropriate support for heavy enclosures. Keep heavier components near the bottom of the rack to reduce the risk of toppling of a top-heavy rack.




Figure 1: The Enclosure Mounting Holes

1.2 BTS500 Rackmount Switch Overview




Figure 2: BTS500 Front View




Figure 3: BTS500 Rear View



The following are basic descriptions. Refer to the appropriate section for more detailed information. Note that the front panel may appear different based on the configuration of your system.

① SFP Ports

Two high speed SFP ports are available, typically used for a fiber connection.

② Ethernet Connections / PoE Outputs (1 - 8)

These ports provide the connections between the LAN and the connected network devices while also supplying PoE power. These ports accept standard RJ45 cables.

③ Reset Button (Reset)

Pressing the recessed reset button with a pin for a length of time will reset the BTS500 as follows:

10 Seconds User Name & Password Only

20 Seconds User Name, Password, and IP Settings

NOTE - The user name and password will both reset to "admin". If pressed for 20 seconds, the IP address will reset to 192.168.1.9 and the other IP settings will return to default.

④ Power Meters (Power 1-4 & Power 5-9)

These meters display voltage and current for the labeled groups of ports. The left side meter provides power information for ports 1-4, while the center meter provides information for ports 5-9.

⑤ Power Meters (Battery)

This meter displays voltage and current for the connected battery set. If no battery set is connected, this meter will show no values.

⑥ AC Line Input (AC Power)

This is the connector for the AC line cord. Plug the included computer-style line cord into this connector. Connect the other end of the cord to the power strip inside the rack or another suitable AC power receptacle. The BTS500 series has a universal input and accepts 90-265VAC input.

⑦ Main AC Power Switch / Circuit Breaker (On/Off)

This is the main AC power switch for the BTS500. This switch lights when power is on and also has a built-in circuit breaker rated at 15A. If the circuit breaker trips, reset it by cycling the switch to off then back to on.

⑧ External DC Voltage Input (External DC +/-)

This input may be used to either power the BTS500 via an external 50VDC supply or to provide battery backup to the BTS500. The "External DC" input is reverse polarity protected. See below for details:

To Use Battery Backup

Connect AC power to the BTS500 unit as normal. In addition, connect a 48V nominal battery set to the "External DC" connector, using the battery cable supplied.

To Use an External 50Vdc Supply

Connect a 50V power supply to the "External DC" connector at the rear. The ratings requirements for the DC power supply are given below:

Input voltage range	44 –57 VDC
Max input current (500W model)	14.0 A
Max input current (250W model)	7.0 A

Note that if both AC and DC power sources are connected to the unit at the same time, the AC source will supply the power to the output ports. The external DC source will not supply the outputs unless the AC source is missing or the power switch is turned off.

⑨ Fire Alarm Input (For BX50 SFI Mode)

This input accepts an input from a Fire Alarm Control Panel (FACP) to activate SFI mode when used with BX50 PoE splitters. See section 1.3 for more information on the Fire Alarm Input and SFI mode.

⑩ RS485 Connection (B, A, GND)

This connector provides an RS485 connection between the BTS500 and any connected LSP accessory boards with an RS485 connection, such as a Generation 2 M8 or M8P.

1.3 Using the Fire Alarm Input for SFI Mode

The BTS500-8R contains a Fire Alarm Input which can be used to activate Single-point Fire Interface mode (SFI) when used with LifeSafety Power's BX50 PoE splitters. SFI mode allows a single FACP connection at the BTS500 to control the lock output of one or more BX50 splitters through the ethernet cable without additional wiring between the BTS500 and BX50, or to the door.


NOTE: Only the BX50 is compatible with SFI mode. Activating SFI on other devices will result in improper operation.

The Fire Alarm Input of the BTS500 consists of 6 terminals for flexibility in connection method. See Figure 4 below for typical wiring diagrams. Connections are as follows:


- **I+ & I- Terminals** These terminals are the input terminals for the FAI input. The FAI input is activated when a voltage between 9 and 28VDC is present on these terminals in the proper polarity.
- **V+ & V- Terminals** These terminals are a low-current auxiliary voltage which can be used for activating the I+ and I- terminals
- **L Terminals** When a NC contact is placed across the L terminals, the FAI input will latch when activated until the NC contact is momentarily opened. If latching is not needed, these terminals should be left disconnected.

Wiring the Fire Alarm Input


Normally Open Contact




Voltage Input



Normally Closed Contact



Latching



Note - NO Activation shown, but any method can be used for FAI activation

Figure 4: Wiring the FAI Input

Section 2 – Initial Configuration

The PowerCom PoE management interface allows users to configure, monitor, and control each output port of the BTS500 series switch. PowerCom PoE is an embedded web browser based interface and does not require the installation of any dedicated software on the user's PC. Any device with a network connection and a web browser may be used to access PowerCom PoE.

2.1 Preparing to configure the BTS500

In order to perform the initial configuration of the BTS500, you will need the following:

- A computer (PC or Mac) set to a static IP address in the subnet 192.168.1.xxx, where xxx is a subnet address (0 to 255) not being used by any other device on the network. Do not use 192.168.1.9 or the final IP address you will be using for the BTS500. (See Figure 5.)
- A CAT5 or higher Ethernet cable long enough to reach between the computer and one of the BTS500's ethernet ports.
- The BTS500 must be powered. After powering, wait approximately 2 minutes for the BTS500 to initialize.

After the BTS500 is powered and initialized, connect the ethernet cable between the ethernet port of the BTS500 and computer.

2.2 Logging into PowerCom PoE for the first time

From the factory, the BTS500 is preset with the following settings:

- IP Address: 192.168.1.9
- Username: admin
- Password: admin

Open a browser on the computer and enter "192.168.1.9" into the address bar. The login screen will appear (See Figure 6). Enter "admin" for both the user name and password.

⚠ If the wrong password is entered three consecutive times, the user will be locked out of the device for 24 hours. Enter the password carefully to avoid lockout.

On first login, the BTS500 will require a password change. Enter a new password and submit. The BTS500 Home Page should appear (See Figure 7).




Figure 5: Example of a PC Ethernet port setting window




Figure 6: PowerCom PoE user login screen

LifeSafety Power **PowerCom**® POE MIDSPAN MANAGER

Home [Configure](#) [RS485](#) [VLAN](#) [Tools](#) admin [Logout](#) Ver: 0.2.40

MODEL: BTS500-8R Site ID **LSP** Total Power 0.00W

Date **Mon Aug 16 2021** Time **15:51:13**

MCU VER: 2.00

Port	Priority	Channel	Device	Enabled	FAI State	Voltage	Current	Power	Class	Status
<input type="checkbox"/> 1	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 2	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 3	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 4	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 5	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 6	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 7	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 8	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault

Battery Status Monitoring

Battery Status: **Not Connected**

Battery Voltage: **1.70** VDC

Figure 7: BTS500-8R Home Page



2.3 Configuring the TCP/IP Settings

In the menu bar at the top of the browser screen, click the "Configure" link. Figure 8 shows the top section of the BTS500 Configure page.

At the top left of the Configure page is the "TCP/IP Settings" area. The settings in this area include:

IP Address

The factory default IP address is set to 192.168.1.9. This address may be changed to any valid IP address. In the event the IP address is later forgotten, press the "Reset" button on the front panel of the BTS500 for 20 seconds and the IP address, default user name, and default password will be reset to factory default values.

Net Mask

Should typically be set to 255.255.255.0 - consult with your IT department for more information.

MAC Address

The MAC Address is factory set and is not programmable by the user.

Gateway IP Address

The default gateway is 192.168.1.1. This value may be changed by the user - consult with your IT department for more information.

DNS0, DNS1 Addresses

The default value for DNS0 and DNS1 are 192.168.1.1. These values may be changed by the user - consult with your IT department for more information.

HTTPS Port

Enter the port used for the HTTPS connection - consult with your IT department for more information.

Enable DHCP

Normally, this option is left unchecked, however in some cases you may want to allow the network to assign an IP address to the BTS500. However, please note that **once you select this option, you will need a network scanning tool to find the BTS500's IP address before you will be able to log into the BTS500 and that the IP address may change periodically.**

You must click the "Submit" button at the bottom right of this area to save the changes in this section. The new settings will take effect after the BTS500 is power cycled, or rebooted.

IPV6 Settings

Below the TCP/IP settings are the IPV6 settings. If required, enter these settings as appropriate. Consult with your IT department for more information. Click submit once the settings are entered. The new settings will take effect after the BTS500

is power cycled, or rebooted.

2.4 Configuring the Time Settings

The Time Settings block (See Figure 8) is where the time and date are programmed into the BTS500. First, select the correct time zone from the drop down list and click Submit. After the time zone is set, the time and date can be set one of three ways:

Manual Entry

Enter the correct time and date in the following format and click the "Submit" button:

For Date: **YYYY MM DD**

For Time: **HH MM SS**

⚠ ALWAYS enter two digits in time field.. ie., 7AM = 07, not 7

The new date and time will take effect immediately.

Sync Date/Time With Computer

The "Sync Date/Time with computer" button will set the date and time of the BTS500 to match the computer currently being used to access the BTS500. The new date and time will take effect immediately.

Sync With NTP Server

To sync the BTS500's time and date with an NTP server, enter one or two NTP server addresses into the NTP Server fields. Click the Get GMT Time button to get the time and date from the NTP server. The BTS500 will periodically update the date and time from the NTP server.

Once set, you must click the "Submit" button to save the time and date settings.

2.5 MSM Settings

These settings are used when connecting the BTS500 to an MSM Enterprise server. Enter the IP address of the MSM Server in the "IP Address" field. Set the Port number as appropriate (typically 9888). Click Submit when done to save the settings. Consult the MSM Enterprise manual for more information.

2.6 Configuring the SNMP Settings

In the SNMP Settings block, under the "Basic" heading, set Read and Write Community to "public" and set Location to a meaningful name of your choice. This entry will help you identify the specific BTS500 when multiple BTS500s are installed on the same subnet. This entry will be read by an SNMP system as "syslocation", OID .1.3.6.1.2.1.1.6. The port used for SNMP may also be changed in this section (161 Default). Be sure to open the SNMP port if accessing SNMP outside your firewall. Below the port number setting, select the trap type (Trap or In-

form). Click the "Submit" button at the bottom of the "Basic" section to save the settings, otherwise you will lose the settings. These settings will take effect after a reboot of the BTS500.

The "Security Name" section of the SNMP Settings block allows you to grant only specified computers (by IP address) SNMP v1 and v2 access. Since v1 and v2 do not have password protection, the Security Name settings add security to v1 and v2 access. The web server is password protected and a user must have the web server password in order to setup a computer in the Security Name settings and gain

v1 and v2 access. Multiple source networks can be added to the Security Name Settings block. Be sure to click the "Submit" button to save the settings. The settings will take effect after a reboot of the BTS500.

The "V3 User" section of the SNMP Settings block allows for a user to set up an SNMP v3 user name and password. With a user name and password, the BTS500 may be accessed from anywhere via the internet by using the SNMP v3 protocol. No security name setup is required for v3 users and multiple v3 users may be set up in the same table. Click the

The screenshot displays the configuration interface for a PowerCom POE MIDSPAN MANAGER. At the top, the device model is identified as BTS500-8R, and the site ID is LSP. The current date is Tue Aug 17 2021, and the time is 07:02:55. The interface is divided into several sections:

- TCP/IP Settings:** Includes fields for IP Address (192.168.1.140), Net Mask (255.255.255.0), MAC Address (00:02:AC:56:11:02), Gateway IP Address (192.168.1.1), DNS0 IP Address (192.168.1.1), DNS1 IP Address (192.168.1.1), and HTTPS Port # (443). There is an option to Enable DHCP.
- Time Settings:** Features a time zone selector set to (GMT-06:00)Central Time(US&Canada), an Insert Date field (Year: 2021, Mon: 08, Day: 17), and an Insert Time field (Hour: 07, Min: 02, Sec: 48). It also includes a Sync Date/Time with computer button and NTP Server fields.
- IPv6 Settings:** Contains fields for IPv6 Address, Prefix Lengths, Gateway IP Address, DNS0 IP Address, DNS1 IP Address, Additional PrefixLen (64), and Additional Gateway. There is an option to Enable DHCP.
- MSM Settings:** Includes Mercury Tunnel Port, Enable Tunnel checkbox, IP Address, Destination Port #, Source Port # (0), Connected Status (NULL), and Group Name.
- SNMP Settings:** Divided into three sub-sections:
 - Basic:** Read Community (publicread), Write Community (publicwrite), Location (LSP), Port # (161), and Trap Type (Trap).
 - Security Name:** A table with columns for Name, Source Network, and a checkbox. One entry is shown: Name: mynetwork, Source Network: 192.168.1.0/24.
 - V3 User:** A table with columns for User Name and Password. One entry is shown: User Name: lsp, Password: 12345678.
- SNMP Trap Receiver:** Fields for IP and Port.
- Traps Version:** Select Traps Version dropdown set to V2C.
- SNMP Inform Log:** Show Inform Log button.

Figure 8: Top section of the BTS500 Configure page



"Submit" button to save the settings, which will take effect after rebooting the BTS500.

The SNMP Trap Receiver IP and Port settings should be set to the proper address for the SNMP Trap receiver. Click the "Submit" button and reboot the BTS500 for the settings to take effect. The SNMP Trap Version may be selected using "Select Trap Version".

2.7 Configuring the Email Settings

The BTS500 can be configured to send email alerts on user-specified conditions and periodic status reports. Underneath the SNMP Settings block on the Configure page is the Email Settings block (See Figure 9).

Under "Receive Addresses", the email address or addresses to receive the alerts and reports should be entered. Up to four recipient email addresses may be entered.

Under "Sender", the settings of the account to send the emails should be entered. These settings include:

Sender SMTP Server	This is the address of the SMTP server for the email provider. Consult with your email provider for this address.
Email Address	This is the email address which the BTS500 will use to send emails.
Email Password	This is the password associated with the Sender's Email account
SMTP Port #	Enter the port number required by your email provider for sending email.
TLS	Check this box if your email provider requires TLS or SSL encryption
Authentication	Choose the proper authentication method for your email provider from the drop-down list. Usually, this is "login". Select "off" to completely disable authentication.
Period	Selects how often the BTS500 sends a regular email status report. The period can vary from 1 hour to 6 months or, if you do not want the BTS500 to send periodic reports, select "Never". Note that the "Period" setting does not affect the sending of email alerts generated on faults or events selected by the user, only the periodic status report.

⚠ Note: *Regarding Microsoft Exchange – By Default, Microsoft Exchange will not accept SMTP connections. To use the BTS500's email functions through Microsoft Exchange, the Exchange service must be configured to allow SMTP connections. Consult with the administrator of your Microsoft Exchange Server.*

⚠ Note: **Click the "Submit" button to save the settings.**


TIP: *Most mobile phone providers have an email address available which will convert an email into an SMS text message. This email address is usually in the form of: (the mobile phone number)@xxxxxx. Consult with your mobile provider for more information. The CSV attachment will be removed, since SMS text messages are not compatible with attachments. Because of this, it is recommended that the SMS email be entered as an ADDITIONAL "Receive Address" on the BTS500, so that the CSV file will still be available via regular email.*

Email Test

Below the Email Settings section is the Email Test section. After configuring the email settings, the Email Test button will send a test email to all Email Receive addresses. Please note that it could take an hour or more to receive the email, depending on the speed of your email server. Clicking the Show Email Log button will show the feedback from the email server. This can be useful for diagnosing email problems.

2.8 VPN Settings

The VPN Settings section is for the discontinued MSM-200 hardware VPN (See Figure 9). The MSM-200 has been replaced with MSM Enterprise. If connecting to an existing MSM-200 system, see the MSM-200 manual for more information.



PowerCom[®] POE MIDSPAN MANAGER

[Home](#)
[Configure](#)
[RS485](#)
[VLAN](#)
[Tools](#)

[admin](#) [Logout](#)

Ver: 0.2.40

Email Settings

Receive Addresses

E-Mail Address 1:

E-Mail Address 2:

E-Mail Address 3:

E-Mail Address 4:

Sender

SMTP Server:

E-Mail Address:

E-Mail Password:

SMTP Port #:

TLS:

Authentication:

Period:

Email Test

VPN Settings

EnableRemoteVPNServer

IP Address

User Name

Password

General Settings

Site ID:

Report Occurrences:

Data buffer interval:

Password Lockout Delay:

User Settings

Authorization

User Name

Password

Verify Password

Password Complexity

Normal complexity: Password must have at least 1 uppercase letter, 1 lowercase letter, 1 number and total length at least 8 characters.
 Enhanced complexity: Password must have at least 1 uppercase letter, 1 lowercase letter, 1 special character, 1 number and total length at least 14 characters.

Figure 9: Middle Section of the BTS500 Configure page



2.9 General Settings

There are four settings in the General Settings section (See figure 9):

Site ID Entered by user. Enter any meaningful name to identify the BTS500 switch unit. This name will be displayed at the top of each page and in email alerts.

Report Occurrences This setting selects how many datapoints are in the CSV file when the BTS500 sends an email. Settings can be from 1 to 1000.

Data Buffer Interval This setting selects how often the BTS500 takes a "snapshot" of the data for the report. Settings range from 5 minutes to 24 hours.

Password Lockout Delay This sets the lockout time after an incorrect password is entered three times. Settings range from 5 minutes to 24 hours.

2.10 User Settings

In the User Settings block of the Configure screen (bottom of Figure 9), you can enter the user names, passwords, access levels, and set the password complexity requirements for the BTS500.

The default user is "admin" and the default password for this account is also "admin". On first login, the BTS500 will force the user to change the default password. Click Submit after making any changes in the User Settings section. Note that there must ALWAYS be at least one admin-level user.

Adding a New User

To add another user, first select the Authorization level desired for the user. Three authorization levels are available:

- **Admin** - Admin-level users have full control over the BTS500. There are no restrictions.
- **Manager** - Manager-level users have access to all areas of the BTS500 except for the Configure page.
- **Guest** - Guest-level users may only view information on the BTS500 screens. No changes can be made and none of the control features are available.

After selecting the Authorization level, enter the new user name in the User Name column and enter the password into the Password column. Passwords must meet the complexity level setting requirements. Re-enter the password into the Verify Password column.

After clicking Submit, the new user will be active and another blank row will appear for entering the next user name.

2.11 Certificate Settings

The BTS500 allows a user-supplied certificate to be used. Click the "Import Certificate" button (Figure 10) to enter the Import Certificate screen. Contact your IT department for more information.

Click the Choose File button to select the certificate to be used, then click Download, then Confirm to download the certificate.

Click the Submit and Test buttons to use and test the certificate.

2.12 SSL Protocol and CipherSuite Settings

This section allows the user to select which SSL protocol to use. The default setting is Normal. See Figure 10

2.13 Certificate Log

Click Show Certificate Log to view the certificate activity log. Click Hide Certificate Log to hide the window. See Figure 10

2.14 Import and Export Configuration File

The BTS500 allows the user to export the configured settings to a file. This file can be used as a backup or to transfer these settings to other BTS500 devices that require similar settings. The settings exported include: Time Settings, MSM Settings, SNMP Settings, VPN Settings, User Settings, Zone Programming

To export the settings, click the Export Configuration File button (See Figure 10). The exported file saves to the default download location of the browser.

To import a configuration file, click the Import Configuration File button to open the Import Settings screen.

Click the Choose File button and select the configuration file to be imported. Click Download, then Confirm to import the settings.

2.15 IEEE802.1x Settings and Log

This section allows the user to set up IEEE802.1x authentication, if required. Click Submit after completing this section. The "Show IEEE802.1x Log" button will show or hide the log on the screen.

The screenshot displays the configuration interface for the PowerCom POE MIDSPAN MANAGER. At the top, the LifeSafety Power logo is on the left, and the product name 'PowerCom® POE MIDSPAN MANAGER' is on the right. A navigation bar includes links for Home, Configure, RS485, VLAN, Tools, admin, and Logout, along with the version number 'Ver: 0.2.40'. A note about password complexity is visible: 'Enhanced complexity: Password must have at least 1 uppercase letter, 1 lowercase letter, 1 special character, 1 number and total length at least 14 characters.'

The main content area is divided into several sections:

- Certificate Settings:** This section is divided into three columns: 'PFX Certificate', 'Certificate Authority', and 'Default Certificate'. Each column contains a 'Certificate:' field with an 'Import Certificate' button, a 'Password:' input field, and a 'Submit' button. A 'Test' button is also present under the PFX Certificate column. A note at the bottom of this section states: 'The current use of the certificate is a default certificate.'
- SSLProtocol and CipherSuite Settings:** This section includes a dropdown for 'SSL Options' (set to 'Normal'), an input field for 'SSL Protocol' (set to 'all -SSLV3'), and a large input field for 'CipherSuite' (set to 'HIGH:MEDIUM:!MD5:!RC4'). A 'Submit' button is located at the bottom.
- Certificate Log:** This section contains a single button labeled 'Show Certificate Log'.
- Import and Export Configuration File:** This section contains two buttons: 'Import Configuration File' and 'Export Configuration File'.
- IEEE802.1x Settings:** This section includes a dropdown for 'EAP Method' (set to 'EAP-MD5'), a checkbox for 'Enable IEEE802.1x', input fields for 'Username' and 'Password', a checkbox for 'Enable Alert', a 'Certificate Expiration' field (set to '30' days), a 'Service Due' field (set to 'No'), and an 'EAP State' field (set to 'NULL'). A 'Submit' button is positioned to the right of the password field.
- IEEE802.1x Log:** This section contains a single button labeled 'Show IEEE802.1x Log'.
- User Login Record:** This section contains a single button labeled 'Show Login Log'.
- User Activity Record:** This section contains a single button labeled 'Show Activity Log'.

Figure 10: Bottom Section of the BTS500 Configure Page



2.16 User Login Record / User Activity Record

Click the Show User Login Record button to show the history of login information for the BTS500. The Show User Activity Record shows the log of activity for each user. See Figure 10

2.17 The Programming Page

Clicking the Programming button on the home page brings up the PoE configuration screen. Figure 11 shows the Programming page of the BTS500.

The programming page allows users to set "Disable on FAI" and optional upper and lower limits for the measured voltage and current of each port. If any of these limits are exceeded, and the "E-Mail Alert" box is checked for the port, an email will be sent to the address configured in Section 2.7 of this manual. This email includes an attached CSV file containing fault details as well as historical data. **NOTE:** The email settings must be configured properly. See Section 2.7 of this manual.

"Fill All" Button (top) - This button will take all settings from Zone 1 and copy them to all other zones.

"Fill All" Buttons (column) - Each column has a "Fill All" button. This button takes the setting from Zone 1 of that column only and copies it to all other zones.

"Import Settings" Button - This button opens a page allowing you to select a BTS500 Configuration file to import. Click the Browse button to select the file, then click open. After selecting the file, click "Download" then "Confirm".

"Export Settings" Button - This button saves the configuration of the BTS500 to a file, which may be imported to other BTS500s. If prompted after clicking, select "Save File".

NOTE: The upper and lower limits entered must be within the allowed range. For voltage limits, the range is 0 to 60V. For current limits, the range is 0 to 1.15A.

NOTE: Disable on FAI should **ONLY** be selected as "Yes" on zones connected to a BX50 PoE splitter. Selecting "Yes" on other devices will result in incorrect operation.

The screenshot shows the PowerCom PoE Midspan Manager interface. At the top, there are navigation links: Home, Configure, RS485, VLAN, Tools, admin, and Logout. The current user is 'admin' and the version is '0.2.40'. Below the navigation is a header bar with 'MODEL: BTS500-8R', 'Site ID: LSP', 'Date: Tue Aug 17 2021', and 'Time: 11:20:30'. There are buttons for 'Return', 'Save Settings', 'Fill All', 'Import Settings', and 'Export Settings'. The main table has columns for Port No., Channel, Device, Disable On FAI, Voltage Lower Limit (V), Voltage Upper Limit (V), Current Lower Limit (A), Current Upper Limit (A), and E-Mail Alert. Each column has a 'Fill All' button above it. The table shows 8 ports, each with Channel A and Channel B settings. The 'Disable On FAI' column has a 'Yes' dropdown menu. The 'E-Mail Alert' column has a checkbox.

Port No.	Channel	Device	Disable On FAI	Voltage Lower Limit (V)	Voltage Upper Limit (V)	Current Lower Limit (A)	Current Upper Limit (A)	E-Mail Alert
1	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
2	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
3	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
4	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
5	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
6	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
7	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>
8	Channel A			0.00	60.00	0.00	1.15	<input type="checkbox"/>
	Channel B		Yes ▾	0.00	60.00	0.00	1.15	<input type="checkbox"/>

Figure 11: Programming page of the BTS500-8R

Section 3 – Using the BTS500

3.1 Viewing Parameters on the BTS500 Home Page

The Home Page is shown in Figure 12. To access the Home Page, click "Home" in the menu bar at the top of the page.

The top of the home page shows general information:

Model Number

This field displays the model number of the BTS500 being accessed.

Site ID

This field is a descriptive name for the BTS500 unit being accessed and is set by the user on the Configure page.

Date and Time

This field shows the date and time as set by the user on the Configure page.

Total Power

This field shows the total power being drawn from all outputs of the BTS500.

Below the top section, there are nine buttons. Their functions are described below:

Enable selected ports

Clicking this button enables PoE on any ports whose checkbox in the "Port" column is checked. After the button is clicked, any ports selected in the "Port" column will be deselected.

Enable all ports

Clicking this button will enable PoE on all output ports of the BTS500 switch.

Disable selected ports

Clicking this button disables PoE on any ports whose checkbox in the "Port" column is checked. After the button is clicked, any ports selected in the "Port" column will be deselected. This function is useful for disabling PoE on unused zones or devices.

LifeSafety Power® PowerCom® POE MIDSPAN MANAGER

Home Configure RS485 VLAN Tools admin Logout Ver: 0.2.40

MODEL: BTS500-8R Site ID LSP Total Power 0.00W

Date Mon Aug 16 2021 Time 15:51:13

Enable Selected Ports Disable Selected Ports Reset Selected Ports View Data

Enable All Ports Disable All Ports Reset All Ports Save Settings Programming MCU VER: 2.00

Port	Priority	Channel	Device	Enabled	FAI State	Voltage	Current	Power	Class	Status
<input type="checkbox"/> 1	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 2	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 3	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 4	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 5	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 6	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 7	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault
<input type="checkbox"/> 8	0	Channel A		Yes	Inactive	0.00V	0.00A	0.00W	N/A	Fault
		Channel B				0.00V	0.00A	0.00W	N/A	Fault

Battery Status Monitoring

Battery Status: Not Connected

Battery Voltage: 1.70 VDC

Figure 12: Home page of the BTS500-8R

Disable all ports

Clicking this button will disable PoE on all output ports of the BTS500 switch.

Reset Selected Ports

Clicking this button will disable PoE power for 10 seconds on any ports whose checkbox in the "Port" column is checked. After 10 seconds, the ports will be reenabled.

Reset All Ports

Clicking this button will disable PoE power on all ports for 10 seconds. After 10 seconds, the ports will be re-enabled.

View Data

Clicking this button will show the history data buffer. Up to 1000 datapoints may be displayed. This data can be manually exported to a CSV file.

Save settings

Clicking this button will save the settings on the page.

Programming

This button brings the user to the PoE Programming page. See section 2.17

Below the buttons is the port information and control area:

Port

This column lists the port numbers with a checkbox to the left of each number. The port numbers in this column refer the port numbers on the front panel of the BTS500. Click the checkboxes to select one or more ports for enabling or disabling. Click the checkboxes again to deselect the port.

Priority

This column allows users to set a priority for each port. For each port there is a corresponding priority drop-down list where a priority between 0 and 3 can be selected (where "0" is the highest priority and "3" is the lowest priority). After the priorities are set, the "Save settings" button at the top of the page must be clicked to save the priority settings.

When the total power drawn from the BTS500 exceeds the rated value (500W), the lowest priority ports will begin disabling to prevent the BTS500 from overloading. **NOTE:** Each port can supply a maximum of 90W of power per the IEEE 802.3bt standard provided that the total power drawn does not exceed the rated power.

NOTE: If two or more ports have the same priority selected, the BTS500 will disable the lowest number port first (i.e. Port 1 will disable, then Port 2 if both are set to the same priority).

Channel

This column shows the channel configuration for the port. This configuration is auto-selected by the BTS500 based on the type of device connected. Single signature PoE devices will appear as "Channel A&B" on a single line. Dual signature devices will show Channel A and Channel B as separate lines.

Device

This column allows the user to enter names for the devices connected to each output port of the BTS500. The maximum length of the entry is 30 characters. After entering the names, click the "Save settings" button at the top of the page.

Enabled

This column shows the enable/disable state of each port. If a port is enabled, the display shows "Yes". If a port is disabled, the display will show "No". See the Enable, Disable, and Reset button descriptions in this section for more information.

FAI State

This column shows the FAI status for each zone as follows:

N/A	FAI is not enabled for the zone
Inactive	FAI is enabled for the zone, but the FAI input is not active. The lock power on the BX50 for this zone is ON
Active	FAI is enabled for the zone and the FAI input is active. The lock power on the BX50 for this zone is OFF.

Voltage

This column displays the measured PoE port output voltage for each port in volts.

Current

This column displays the measured PoE port output current for each port in milliamps.

Power

This column displays the calculated power output of each PoE port in watts.

Class

This column displays the power class of each port. The "power class" information is provided by the connected Powered Device (such as a PoE compatible IP camera) during the power interface between the BTS500 and the Powered Device. When a port is not connected to a load (Powered Device), or when a port is disabled, the class display shows "N/A".

Status

This column displays the status of each output port.

When a port is normal (a Powered Device is drawing power within the specified limits), the corresponding status will display “Normal” with a green background. If there are any fault conditions or a valid PoE device is not connected the corresponding status will display “Fault” with a yellow background. If a port is disabled by the browser interface, the corresponding status will display “Disabled” with a grey background.

3.2 The RS485 page

The BTS500 has a rear-panel RS485 connector for communicating with LifeSafety Power accessory boards containing an RS485 connection, such as the generation 2 M8 or M8P boards. To access these devices, click the RS485 top menu item (See Figure 13).

Any devices connected to the BTS500 through the RS485 interface will appear on this page with the device's model, location, and status. Clicking on the device will open the device's interface. See the manual for the connected device for more information on usage and configuration.

3.3 The Tools page

Upgrading Firmware

The Upgrade Firmware section is at the top left of the Tools page (See Figure 14). To upgrade the firmware, use the following steps:

1. Ensure that the new firmware file is available on your computer. The latest firmware file is available from the LifeSafety Power website.
2. Click the "Upgrade" button. The Upgrade window will appear.
3. Click "Browse..." and locate the new firmware file with the file extension ".bin" on your computer.
4. Once the file is selected, click "Open".
5. Click the "Download" button to temporarily download the new firmware into the RAM of the BTS500. This process will take from 30 seconds to one minute, depending on network speed and traffic. The message box will display "Downloading...".
6. Once the firmware is loaded into the BTS500's RAM, verify the correct file name and click the "Confirm" button to confirm the upgrade.




Figure 13: The RS485 page of the BTS500

- Click "Burn" to begin burning the firmware to the BTS500's processor. This process may take up to 12 minutes - DO NOT REMOVE POWER TO THE BTS500 DURING THIS PROCESS or the BTS500 will be rendered nonfunctional.

Once the update is complete, a message will appear in the message box indicating "Update Finished". The BTS500 must be rebooted in order to start the new firmware.

Rebooting the BTS500

The "Reboot" section is on the top right of the Tools page (See Figure 14). To reboot the BTS500, click the "Reboot Switch" button.

A message will appear asking if you are sure you want to reboot. Click YES to Confirm the reboot. The rebooting process will take approximately 1 minute, during which time you will lose communication with the BTS500.

User Notes

The bottom of the Tools page contains a User Notes section where important information about the installation, service history, etc can be saved. Up to 1000 characters can be entered. After entering the notes, click "Submit" to save them. The "Clear" button will remove the notes.

The screenshot displays the 'Tools' page of the PowerCom POE MIDSPAN MANAGER interface. At the top, the LifeSafety Power logo is on the left, and the PowerCom POE MIDSPAN MANAGER title is on the right. Below the title bar is a navigation menu with links for Home, Configure, RS485, VLAN, Tools, and admin Logout. The version number 'Ver: 0.2.40' is shown in the top right corner. The main content area is divided into two sections: 'Upgrade Firmware' and 'Reboot'. The 'Upgrade Firmware' section contains an 'Upgrade' button. The 'Reboot' section contains a 'Reboot Midspan' button. Below these sections is a 'User Notes(up to 1000 characters)' section with a large text input area and 'Save' and 'Clear' buttons at the bottom.

Figure 14: The Tools page of the BTS500

Appendix 1 – Software Agreement

LIFESAFETY POWER SOFTWARE LICENSE AGREEMENT AND WARRANTY STATEMENT

NOTICE: PLEASE READ THIS DOCUMENT CAREFULLY. This Software License Agreement (“AGREEMENT”) defines and governs use of LIFESAFETY POWER Software and includes WARRANTY DISCLAIMERS. Your acceptance of this AGREEMENT is an acknowledgement, representation and warranty that you have the full right and authority to enter into, execute, and perform obligations under this AGREEMENT, or that you have the authority to enter into and execute this AGREEMENT as an Authorized Representative of a business entity or corporate entity and to bind that business entity or corporate entity to perform obligations under this AGREEMENT by your acceptance, acknowledgment and representation.

TERMS AND CONDITIONS

1. Definitions.

(a) “Authorized Representative” refers to any person duly authorized by a business entity or corporate entity (i.e. a “legal entity”) to enter into this AGREEMENT and to bind the legal entity to the terms and conditions herein.

(b) “Recipient” refers to any individual or legal entity, entering into and executing this AGREEMENT for purposes of use of LIFESAFETY POWER Software, where “use” is as defined by this AGREEMENT.

(c) “Documentation” refers to any related explanatory written materials or files including, without limitation, any end-user manual, specifications or other written materials provided to Recipient for the Software.

(d) “Facility” refers to any facility where LIFESAFETY POWER Equipment is located and/or where the Software is installed or used under control of Recipient in conjunction with such Equipment.

(e) “Software” refers to all the contents of files provided to Recipient by electronic download, on physical media (including EEPROM or ROM chips etc.) and/or any other method of distribution, disk(s), CD-ROM(s), DVD-ROM(s), or other media with which this AGREEMENT is provided, including, without limitation, fonts, graphics, user-interfaces, Upgrades, updates, additions to, and any copies of the foregoing, provided to Recipient by LIFESAFETY POWER.

(f) “Upgrades” refers to new versions, updates, and revisions of the Software provided to Recipient by LIFESAFETY POWER.

(g) “Use” refers to actions taken exclusively by Recipient to copy for backup purposes, download, install, access, and to enjoy and benefit from features and functionality of the Software, subject to all restrictions set forth in this Agreement.

2. License and Restrictions.

(a) Grant of Rights. LIFESAFETY POWER hereby grants Recipient a non-exclusive license to have one (1) copy of the Software in Recipient’s possession and control at one (1) facility of Recipient. Recipient may install the Software and may access the Software by concurrent users over a network connection in accordance with the Documentation. Recipient may also make one (1) additional copy for backup or archival purposes at one (1) Recipient facility which may be a different Recipient facility from where the other Software copy is installed and used. Recipient may also Upgrade the Software subject to Upgrades that may be provided from time-to-time by LIFESAFETY POWER at its sole discretion. The Software, subsequent to any Upgrade, shall be subject to the same terms, conditions and restrictions as provided herein, and shall also be subject to any other applicable modifications or amendments to this AGREEMENT that may accompany the Upgrade as provided for herein. Recipient shall comply with all restrictions set forth in this AGREEMENT.

(b) Reservation of Rights. Copies of the Software created or transferred pursuant to this Agreement are licensed, not sold, and Recipient receives no title to, or ownership of, any copy or of the Software itself. The Software is protected by copyright laws, and by international treaty provisions, and includes trade secrets of LIFESAFETY POWER, and Recipient shall not disclose it to any third party except to the extent required by law. Furthermore, Recipient receives no intellectual property rights or any other rights to the Software other than those specifically granted in Section 2(a). Any rights not expressly granted in Section 2(a) are reserved by LIFESAFETY POWER.

(c) Restrictions. Without limiting the generality of the foregoing, Recipient shall not: (i) modify, create derivative works from, distribute, publicly display, publicly perform, or sublicense the Software; (ii) use the Software for service bureau or time-sharing purposes or in any other way allow third parties to exploit

the Software; or (iii) reverse engineer, decompile, disassemble, or otherwise attempt to derive any of the Software’s source code.

(d) No Distribution, No Modification, No Derivative Works. Recipient shall not network, rent, lend, loan, distribute or create derivative works based upon the Software in whole or in part; or electronically transmit the Software from one computer to another or over a network. Recipient shall not modify, adapt, translate or create derivative works based upon the Software.

(e) No Reverse Engineering. Recipient shall not engage in, or induce a third party to engage in, reverse engineering of the Software. “Reverse Engineering” means i) the disassembly, decompilation, decryption, simulation, debugging or code tracing of microcode; and/or ii) the disassembly, decompilation, decryption, simulation, debugging or coded tracing of object code or executable code, specifically including, but not limited to, any LIFESAFETY POWER supplied or developed libraries or microcode. Regarding any of LIFESAFETY POWER’s software and/or firmware “Reverse Engineering” shall also mean iii) the act of producing computer program “source code” that, when compiled, will generate computer programs that provide the same, or similar functions as the Software, by means of translating the object code, which may be provided by LIFESAFETY POWER under this Agreement, (including object code in ROM memory chips as well as object code provided on computer-readable magnetic media or object code provided by downloading, from the computer binary instructions into equivalent programming language instructions, in assembly language or other computer programming language). This term is also intended to include the development of software that incorporates the methods, techniques, styles and approaches of the Software, while performing similar functions.

(f) No Exportation. Recipient shall not ship, transfer or export the Software into any country or use the Software in any manner prohibited by the United States Export Administration Act or any other export laws, restrictions or regulations (collectively the “Export Laws”). In addition, if the Software is identified as export controlled items under the Export Laws, you represent and warrant that you are not a citizen, or otherwise located within, an embargoed nation (including without limitation Iran, Syria, Sudan, Cuba, and North Korea) and that you are not otherwise prohibited under the Export Laws from receiving the Software. All rights to use the Software are granted on condition that such rights are forfeited if you fail to comply with the terms of this agreement.

(g) Assignment & Successors. The rights and obligations under this AGREEMENT may not be assigned, without the express prior written consent of all the Parties, provided, however, consent to assignment of the rights and obligations hereunder as part of the sale of a Recipient’s entire business relevant to this AGREEMENT shall not be required. Furthermore, either party may assign this AGREEMENT to the surviving party in a merger of that party into another entity. Incept to the extent forbidden above, this AGREEMENT will be binding upon and inure to the benefit of the respective successors and assigns of the parties.

(h) Third Party Interoperability. The Software may interoperate with and allow you to use software applications, information and data not developed or offered by LIFESAFETY POWER (“Third Party Information”). Your use of any Third Party Information is governed by the terms and conditions made available to you by the party from whom you obtained such information. Unless otherwise agreed by LIFESAFETY POWER in writing, Third Party Information is not the responsibility of LIFESAFETY POWER. YOUR USE OF THIRD PARTY INFORMATION IS AT YOUR OWN RISK. LIFESAFETY POWER MAKES NO WARRANTIES, CONDITIONS, INDEMNITIES, REPRESENTATIONS OR TERMS, EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE AS TO ANY MATTERS, INCLUDING BUT NOT LIMITED TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, TITLE, INTEGRATION, INTEROPERABILITY, ACCURACY, SECURITY, AVAILABILITY, SATISFACTORY QUALITY, MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH RESPECT TO THIRD PARTY INFORMATION.

(i) Notices. Recipient shall not remove or alter any copyright, trademark or other proprietary notice that appears on or in the Software.

(j) Software License Compliance Audit. LIFESAFETY POWER may audit Recipient’s use of the Software on thirty (30) days’ advanced written notice. Recipient agrees to cooperate with the audit, including by providing access to any books, computers, records, or other information that relate or may relate to use of the Software. Such audit will not unreasonably interfere with Recipient’s business activities. In the event that an audit reveals unauthorized use of the Software, Re-



Appendix 1 – Software Agreement - continued

Recipient shall reimburse LIFESAFETY POWER for the reasonable cost of the audit, in addition to such other rights and remedies as LIFESAFETY POWER may have. LIFESAFETY POWER will not conduct an audit more than once per year.

(k) Trademarks. No rights whatsoever to use any trademarks, registered or unregistered, are granted by any provision of this AGREEMENT.

3. Upgrades.

(a) Upgrades. LIFESAFETY POWER may provide Recipient with copies of Upgrades without additional charge, from time-to-time. Upon delivery to Recipient, Upgrades will become part of the Software and will be subject to all provisions of this AGREEMENT.

(b) Upgrades and Software License Agreement Terms. LIFESAFETY POWER may require additional terms that are additional to this AGREEMENT or that modify or amend this AGREEMENT upon Recipient's installation and use of Upgrades. Any such additional terms, modified or amended terms will require Recipient's execution of a new Agreement which will subsequently replace and supersede this AGREEMENT. Recipient may reject such additional terms, modified or amended terms by not downloading or installing the associated Upgrade(s).

(c) Reservations regarding Upgrades. LIFESAFETY POWER may cease providing Upgrades at any time and/or may cease providing Upgrades without additional charge and may require an additional charge for Upgrades at any point in time without notice. Recipient will be informed of any such additional charges at the time of requesting such Upgrades. Upgrades may be requested by downloading or by requesting other forms of delivery.

4. DISCLAIMER OF WARRANTIES.

(a) "AS-IS" SOFTWARE. THE SOFTWARE (AS DEFINED IN THIS AGREEMENT) IS PROVIDED ON AN "AS IS", "AS AVAILABLE" BASIS AND WITH ALL FAULTS.

(b) WARRANTY DISCLAIMERS, NO WARRANTY. LIFESAFETY POWER MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. LIFESAFETY POWER MAKES NO WARRANTIES, CONDITIONS, REPRESENTATIONS, OR TERMS (EXPRESS OR IMPLIED WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE) AS TO ANY MATTER INCLUDING WITHOUT LIMITATION PERFORMANCE, RESULTS, NON-INFRINGEMENT OF ANY PARTY'S RIGHTS, MERCHANTABILITY, INTEGRATION, SATISFACTORY QUALITY, OR FITNESS FOR ANY PARTICULAR PURPOSE.

(c) LIFESAFETY POWER PROVIDES NO TECHNICAL SUPPORT OR REMEDIES FOR THE SOFTWARE.

(d) LIFESAFETY POWER does not warrant that the Software will perform without error or that it will run without immaterial interruption. LIFESAFETY POWER provides no warranty regarding, and will have no responsibility for, any claim arising out of: (i) a modification of the Software; or (ii) use of the Software in combination with any operating system or Third Party Information not authorized in the Documentation or with hardware or software specifically forbidden by the Documentation.

5. LIMITATION OF LIABILITY.

(a) Limitations. Except as provided below: (i) IN NO EVENT WILL LIFESAFETY POWER'S, OR ANY OF ITS OFFICERS', DIRECTORS', SHAREHOLDERS', PARENTS', SUBSIDIARIES', AGENTS', INSURERS', SUCCESSORS', AND/OR ASSIGNS', LIABILITY ARISING OUT OF OR RELATED TO THIS AGREEMENT EXCEED THE AGGREGATE OF FEES PAYABLE TO LIFESAFETY POWER PURSUANT TO THIS AGREEMENT (INCLUDING FEES BOTH PAID AND DUE) AT THE TIME OF THE EVENT GIVING RISE TO THE LIABILITY; AND (ii) IN NO EVENT WILL LIFESAFETY POWER OR ANY OF ITS OFFICERS, DIRECTORS, SHAREHOLDERS, PARENTS, SUBSIDIARIES, AGENTS, INSURERS, SUCCESSORS, AND/OR ASSIGNS BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, SPECIAL, INCIDENTAL, OR PUNITIVE DAMAGES. THE LIABILITIES LIMITED BY THIS SUBSECTION 5(a) APPLY: (A) TO LIABILITY FOR NEGLIGENCE; (B) REGARDLESS OF THE FORM OF ACTION, WHETHER IN CONTRACT, TORT, STRICT PRODUCT LIABILITY, OR OTHERWISE; (C) EVEN IF LIFESAFETY POWER, AND/OR ANY OF ITS OFFICERS, DIRECTORS, SHAREHOLDERS, PARENTS, SUBSIDIARIES, AGENTS, INSURERS, SUCCESSORS, AND/OR ASSIGNS IS/ARE ADVISED IN ADVANCE OF THE POSSIBILITY OF THE DAMAGES IN QUESTION AND EVEN IF SUCH DAMAGES WERE FORESEEABLE; AND (D) EVEN IF RECIPIENT'S REMEDIES FAIL OF THEIR ES-

SENTIAL PURPOSE. If applicable law limits the application of the provisions of this Section 5(a), LIFESAFETY POWER's liability will be limited to the maximum extent permissible.

(b) Further Limitations. IN NO EVENT WILL LIFESAFETY POWER OR ANY OF ITS OFFICERS, DIRECTORS, SHAREHOLDERS, PARENTS, SUBSIDIARIES, AGENTS, INSURERS, SUCCESSORS, AND/OR ASSIGNS BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, SPECIAL, INCIDENTAL, OR PUNITIVE DAMAGES ARISING OUT OF OR RELATED TO ANY OF THE FOLLOWING:

(i) revisions to the Software made without the express, written consent of LIFESAFETY POWER;

(ii) Recipient's failure to incorporate Software Upgrades that would have avoided the alleged liability, provided LIFESAFETY POWER offered such Upgrades without fees or charges and with notice to Recipient thereof;

(iii) use of the Software in combination with hardware or software or Third Party Information not provided by LIFESAFETY POWER: (A) that is specifically forbidden by the Documentation; or (B) that is not designated in the Documentation as available for interface with the Software.

6. Term and Termination.

(a) Term. This AGREEMENT shall remain in effect so long as the Recipient continues to use and/or maintain any copies of the Software within Recipient's possession or control in any storage medium without limitation.

(b) Termination for Cause. Either party may terminate this AGREEMENT for material breach by written notice, effective in 30 days unless the other party first cures such breach.

(c) Effects of Termination. Upon termination of this AGREEMENT, the licenses granted herein shall terminate and Recipient shall cease all use of the Software and delete all copies in its possession or control. The following provisions will survive termination of this AGREEMENT: (i) any obligation of Recipient to pay for Software and/or Upgrades rendered before termination; (ii) Sections 4, 5 and 7 of this AGREEMENT; and (iii) any other provision of this AGREEMENT that must survive termination to fulfill its essential purpose.

7. Miscellaneous.

(a) Notice and Contact Information. LIFESAFETY POWER may be contacted at the mailing address below or by the LIFESAFETY POWER website. Notices pursuant to this AGREEMENT should be sent to the address below, or to such others as may be provided in writing. Such notices will be deemed received at such addresses upon the earlier of (i) actual receipt or (ii) delivery in person, by fax with written confirmation of receipt, or by certified mail return receipt requested.

(i) Corporate Headquarters, Mailing Address: LIFESAFETY POWER, 10027 S 51st Street, Suite 102, Phoenix AZ 85044 USA.

(ii) Website Address: www.lifesafetypower.com

(b) Independent Contractors. The parties are independent contractors and will so represent themselves in all regards. Neither party is the agent of the other and neither may bind the other in any way. Nothing in this AGREEMENT is intended or shall be construed to create between the Parties a relationship of principal and agent, partners, joint venturers, or employer and employee. No Party shall hold itself out to others or seek to bind or commit another Party in any manner inconsistent with this AGREEMENT.

(c) No Waiver. Neither party will be deemed to have waived any of its rights under this AGREEMENT by lapse of time or by any statement or representation other than (i) by an Authorized Representative and (ii) in an explicit written waiver. No waiver of a breach of this AGREEMENT will constitute a waiver of any prior or subsequent breach of this AGREEMENT.

(d) Force Majeure. To the extent caused by force majeure, no delay, failure, or default will constitute a breach of this AGREEMENT.

(e) Choice of Law & Jurisdiction. This AGREEMENT shall be governed solely by the internal laws of the State of Illinois, without reference to such State's principles of conflicts of law. The parties consent to the personal and exclusive jurisdiction of the federal and state courts of Illinois, United States of America.

(f) Severability. All of the provisions of this AGREEMENT are intended to

LifeSafety Power
10027 S 51st Street, Suite 102
Phoenix, AZ 85044 USA

www.lifesafetypower.com
Tel (888) 577-2898
info1@lifesafetypower.com

LifeSafety Power, FlexPower, NetLink, GreenSmart, FlexConnect, PowerCom, Reliability+, SureCharge, TruWatt, and VSelect are trademarks or registered trademarks of LifeSafety Power or its affiliates.

Important: All information, including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of each product for their particular application. LifeSafety Power makes no warranties as to the accuracy or completeness of the information, and disclaims any liability regarding its use. LifeSafety Power's only obligations are those in the LifeSafety Power Standard Terms and Conditions of Sale for this product, and in no case will LifeSafety Power or its distributors be liable for any incidental, indirect, or consequential damages arising from the sale, resale, use, or misuse of the product. Specifications are subject to change without notice. In addition, LifeSafety Power reserves the right to make changes—without notification to Buyer—to processing or materials that do not affect compliance with any applicable specification.