BluB0X Integration

NetLink integration with BluB0X provides alerts, measurements, and control capabilities to BluSKY. Power system alerts, measurements, and system control features are available directly from the BluSKY interface, streamlining system maintenance and maximizing system uptime.

Integration to BluSKY is via PSIA/XML and is supported by BluB0X.



Requirements & Information

Item

Information

BluSKY Version Supported

BluB0X License Required

NetLink Boards Supporte NL2, NL4

NetLink Minimum Firmwa 2e1 Versialnove

Integration Type PSIA / XML

Integration Level Full

Supported Alert Supported

AC Fault Alert

System Fault Alert

Fire Alarm Active

Power Supply Service Due

Insufficient Battery Standby Time

Battery Replacement Due 1

M8 Output Voltage Out of Range

M8 Output Current Out of Range

Enclosure Temperature Oūt of Range

External Temperature (ID® Closet) Out of Range

Tamper Switch Alert

Device Detect (Connected or disconnected from NetLink)

Current Sensor Out of Range

Auxiliary Voltage Out of Range

Values Reported Value Supported

AC Input Voltage
Power Supply Output Voltage
Power Supply Total Output Current
Battery Voltage

Battery Charge / Discharge Current
M8 Output (Lock) Voltage
M8 Output (Lock) Current
M8 Output (Lock) Cycle Count
Enclosure Temperature
External Temperature (IDF Closet)
Current Sensor Measurement
Auxiliary Voltage Measurement

Control Features

Control Item

Supplement

Control Features Control Item Supported
Start / Schedule Automated Battery Test
Power Cycle M8 Output
Power Cycle Power Supply Main Output
NetLink Control 1 / Control 2 Outputs