





## OVERVIEW

The NLx Scanner software allows the user to find any Life-Safety Power network devices within a local network. The NLx Scanner will provide the IP Address and Site ID of each

LifeSafety Power device found when DHCP is enabled on the device or if the IP address is forgotten.

[illegible]



### **1 Network Interface**

Select the network connection to use for the scan. Typically, "*Local Area Connection*" should be selected.

### **2 Subnet**

Check this box if you want to restrict the scan to a specific range of IP addresses. Enter the beginning and ending IP addresses in the **From** and **To** fields.

### **3 Include IP Saver**

Check this box to include any **IP SAVER** devices on the network in the scan.

### **4 Site ID**

This is the Site ID of the LifeSafety Power device as programmed in the device's "*Configure*" page.

### **5 IP Address**

This is the IP address of the LifeSafety Power device. Click this IP address to open the device's interface.

### **6 Scan Button** - Click this button to start the scan.

### **7 Stop Button** - Click this button to stop a scan already in progress.



