

Q. How do I set the jumpers on my C4/C8 board?

A. The C4/C8 manual contains a [chart of jumper settings](#) for every common configuration. Also, [pages 2 and 3](#) of the manual contain descriptions for each jumper to allow for less common configurations. Also, the Excel-based [C4/C8 Configuration Tool](#) allows quick and easy determination of jumper settings based on information entered. See [Application Note AN-29](#) for more information