

# RS ISCAN Series Managed Distribution

8 or 16 fully network managed lock outputs in single or dual voltage 12 or 24VDC configurations. UL/CUL/CE Listed



{jatabs type="content" position="top" width="650" heightTabs="30" height="980" mousetype="click" animType="animMoveHor" skipAnim="false" duration=1000 } [tab title="Products"]

	Model No.	Voltage	Power	Outputs
	Bulk	Managed	Auxiliary	
<a href="#">RS75-M8</a>	Single 12 or 24	6A/12V or 3A/24V	2	
<a href="#">RS150-M8</a>	Single 12 or 24	12A/12 or 6A/24	2	8
<a href="#">RS250-M8</a>	Single 12 or 24	12A/12 or 6A/24	2	8
<a href="#">RS150-M16</a>	Single 12 or 24	12A/12 or 6A/24	2	
<a href="#">RS250-M16</a>	Single 12 or 24	20A/12 or 10A/24	2	
<a href="#">RS150B-M16</a>	Dual 12 & 24	4A/12 & 4A/24	2	
<a href="#">RS150B-D8M8</a>	Dual 12 & 24	4A/12 & 4A/24	2	
<a href="#">RS250B-M16</a>	Dual 12 & 24	4A/12 & 8A/24	2	

[RS250B-D8M8](#)

Dual 12 & 24

4A/12 & 8A/24

2

[/tab] [tab title="Overview"]

RS Series power supplies provide 8 or 16 fully network managed lock outputs in single or dual voltage 12 or 24VDC configurations ranging from 75 to 250 Watts total output power. Monitoring and email reporting includes the main power supply as well as the outputs, which can be individually monitored for voltage/current and individually remotely power cycled. Managed outputs each have an input selectable for NO/NC dry contact, voltage, or open collector input. Outputs are selectable for fail-safe or fail-secure. Available in 8 or 16 zone versions, each output is fused at 3A and is protected against surges. Factory set for 120VAC input, it can be user configured for a 230VAC input.

Features include removable terminal strips for field wiring, input and output surge suppression, automotive blade fuses for improved reliability, a front removable chassis face plate for serviceability, and a 16 gauge steel 2U rack mount or wall mount chassis.

## Product highlights

- Agency listed for Access Control, Security, CCTV, Mass Notification
- SurgeShield - enhanced input and output surge suppression
- Multiple outputs for system power and direct lock control
- Microprocessor dual rate charging restores battery sets from 4 to 80Ah
- Fire Alarm Interface (FAI) with latch mode for Canada
- Configurable fail-safe / fail-secure modes of operation
- Comprehensive fault detection and reporting
- Continuous or switched DC selectable per output by positional jumper
- Removable jumper for individual output disconnect
- Enhanced input and output surge suppression
- Programmable system and AC fault alerts
- User enabled earth ground and battery presence jumpers
- Front removable chassis face plate for serviceability
- Automotive blade fuses for improved reliability
- Removable 3 wire grounded AC line cord
- NL1 DataLink network communication interface option

## Reliability and Safety

- RoHS Compliant
- 10 year warranty

## Agency Listings

- UL 294 / UL 603 / UL 864
- UL 1076 / UL 1481 / UL 2044 / UL 2572
- ULC S318, 319, 527
- FCC Part 15, Subpart B
- CSA C22.2 107.1
- CSA C22.2 #60950
- CE
- CSFM Approved



## [Product Warranty](#)

[/tab] [tab title="Technical Documents"]

Model #	Datasheet	Install Manual	CAD Files
---------	-----------	----------------	-----------

[DS](#) [IM](#) [CAD](#) [AG](#)

[/tab] [tab title="Support"]

[Troubleshooting Guide](#)      [Factory Contact](#)      [Business Contact](#)

[FPO Troubleshooting](#)   [Email Customer Service](#)   [Accounting Office](#)

[Accessory Troubleshooting](#)   [Email Technical Department](#)   [Area Sales Representatives](#)

[/tab] [tab title="Tools & Software"] **Tools & Software**

Excel spreadsheets designed by the LifeSafety Power technical department to aid the installer in required calculations and example configurations of LifeSafety Power equipment when used in commonly found system applications.

Calculators / Software

[PowerCom-USB Download](#)

[Ohms Law Calculator](#)

[Battery Size Calculator](#)

[Battery Capacity Calculator](#)

[Wire Size Calculator](#)

[Voltage Drop Calculator](#)

[FlexCalculator Suite](#)

Application Notes  
[AN20 LSP Monitoring Guide](#)

[/tab] {/jatabs}